



# A76XX Series\_ CTBURST\_Application Note

LTE Module

## **SIMCom Wireless Solutions Limited**

SIMCom Headquarters Building, Building 3, No. 289 Linhong Road, Changning District, Shanghai P.R. China

Tel: 86-21-31575100

[support@simcom.com](mailto:support@simcom.com)

[www.simcom.com](http://www.simcom.com)

<b>Document Title:</b>	A76XX Series_CTBURST_Application Note
<b>Version:</b>	1.03
<b>Date:</b>	2022.12.20
<b>Status:</b>	Released

## GENERAL NOTES

SIMCOM OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS, TO SUPPORT APPLICATION AND ENGINEERING EFFORTS THAT USE THE PRODUCTS DESIGNED BY SIMCOM. THE INFORMATION PROVIDED IS BASED UPON REQUIREMENTS SPECIFICALLY PROVIDED TO SIMCOM BY THE CUSTOMERS. SIMCOM HAS NOT UNDERTAKEN ANY INDEPENDENT SEARCH FOR ADDITIONAL RELEVANT INFORMATION, INCLUDING ANY INFORMATION THAT MAY BE IN THE CUSTOMER'S POSSESSION. FURTHERMORE, SYSTEM VALIDATION OF THIS PRODUCT DESIGNED BY SIMCOM WITHIN A LARGER ELECTRONIC SYSTEM REMAINS THE RESPONSIBILITY OF THE CUSTOMER OR THE CUSTOMER'S SYSTEM INTEGRATOR. ALL SPECIFICATIONS SUPPLIED HEREIN ARE SUBJECT TO CHANGE.

## COPYRIGHT

THIS DOCUMENT CONTAINS PROPRIETARY TECHNICAL INFORMATION WHICH IS THE PROPERTY OF SIMCOM WIRELESS SOLUTIONS LIMITED. COPYING, TO OTHERS AND USING THIS DOCUMENT, ARE FORBIDDEN WITHOUT EXPRESS AUTHORITY BY SIMCOM. OFFENDERS ARE LIABLE TO THE PAYMENT OF INDEMNIFICATIONS. ALL RIGHTS RESERVED BY SIMCOM IN THE PROPRIETARY TECHNICAL INFORMATION, INCLUDING BUT NOT LIMITED TO REGISTRATION GRANTING OF A PATENT, A UTILITY MODEL OR DESIGN. ALL SPECIFICATION SUPPLIED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE AT ANY TIME.

### **SIMCom Wireless Solutions Limited**

SIMCom Headquarters Building, Building 3, No. 289 Linhong Road, Changning District, Shanghai P.R. China

Tel: +86 21 31575100

Email: [simcom@simcom.com](mailto:simcom@simcom.com)

### **For more information, please visit:**

<https://www.simcom.com/download/list-863-en.html>

### **For technical support, or to report documentation errors, please visit:**

<https://www.simcom.com/ask/> or email to: [support@simcom.com](mailto:support@simcom.com)

# About Document

## Version History

Revision	Date	Owner	Description
V1.00	2021.10.29	Yulong.zheng	New version
V1.01	2021.03.07	Yulong.zheng	Delete CAT1
V1.02	2022.05.05	Yulong.zheng	Modify Scope
	2022.07.04	Bobo.shao	Add B31 and B72
V1.03	2022.12.19	Bobo.shao	Modify Scope

SIMCom  
Confidential

## Scope

Based on module AT command manual, this document will introduce CTBURST application process. Developers could understand and develop application quickly and efficiently based on this document. This document applies to ASR Series except ASR1802S.

SIMCom  
Confidential

# Contents

<b>About Document</b> .....	<b>2</b>
Version History .....	2
Scope .....	3
<b>Contents</b> .....	<b>4</b>
<b>1 Introduction</b> .....	<b>5</b>
1.1 Purpose of the document .....	5
1.2 Related documents .....	5
1.3 Conventions and abbreviations .....	5
<b>2 AT Commands for CTBURST</b> .....	<b>6</b>
2.1 Overview of AT Commands for CTBURST .....	6
2.2 AT+CTBURST The TX/RX Burst Test .....	6
<b>3 CTBURST Examples</b> .....	<b>10</b>

SIMCom  
Confidential

# 1 Introduction

## 1.1 Purpose of the document

Based on module AT command manual, this document will introduce RF TX/RX application process. Developers could understand and develop application quickly and efficiently based on this document.

## 1.2 Related documents

[1] A76XX Series\_AT Command Manual

## 1.3 Conventions and abbreviations

In this document, the GSM engines are referred to as following term:

ME (Mobile Equipment);

MS (Mobile Station);

TA (Terminal Adapter);

DCE (Data Communication Equipment) or facsimile DCE (FAX modem, FAX board);

In application, controlling device controls the GSM engine by sending AT Command via its serial interface.

The controlling device at the other end of the serial line is referred to as following term:

TE (Terminal Equipment);

DTE (Data Terminal Equipment) or plainly "the application" which is running on an embedded system;

## 2 AT Commands for CTBURST

### 2.1 Overview of AT Commands for CTBURST

Command	Description
<b>AT+CTBURST</b>	Set TX/RX Power

### 2.2 AT+CTBURST The TX/RX Burst Test

AT+CTBURST The RF TX Burst Test	
Test Command <b>AT+CTBURST=?</b>	Response <b>+CTBURST=0-2,0-142,1-65535,-5000-3500, 0-5</b>
	<b>OK</b>
	Response If mode is 0 <b>+CTBURST: TX/RX OFF</b>
	<b>OK</b>
	If mode is 1 <b>+CTBURST: TX ON</b>
	<b>OK</b>
Write Command <b>AT+CTBURST=&lt;mode&gt;[,&lt;band&gt;,&lt;channel&gt;,&lt;power&gt;[,&lt;bandwidth&gt;]]</b>	If mode is 2 For gsm/wcdma <b>+CTBURST: RX [rssiValue]</b>
	<b>OK</b>
	For LTE <b>+CTBURST: RX: [mainRssiValue], [secRssiValue]</b>
	<b>OK</b>
Parameter Saving Mode	NO_SAVE
Max Response Time	-

Reference

-

## Defined Values

<b>&lt;mode&gt;</b>	<p>Start/stop TX/RX the burst/waveform</p> <ul style="list-style-type: none"> <li>0 – stop RF TX/RX</li> <li>1 – start RF TX</li> <li>2 – start RF RX</li> </ul>
<b>&lt;band&gt;</b>	<p>The band of burst/waveform to be sent</p> <ul style="list-style-type: none"> <li>0 – GSM 850 Band</li> <li>1 – GSM 900 Band</li> <li>2 – EGSM 900 Band</li> <li>3 – GSM DCS 1800 Band</li> <li>4 – GSM PCS 1900 Band</li> <li>10 – WCDMA IMT 2000 Band</li> <li>11 – WCDMA PCS 1900 Band</li> <li>12 – WCDMA 800 Band</li> <li>13 – WCDMA 850 Band</li> <li>14 – WCDMA 900 Band</li> <li>101 – LTE 1 Band</li> <li>102 – LTE 2 Band</li> <li>103 – LTE 3 Band</li> <li>104 – LTE 4 Band</li> <li>105 – LTE 5 Band</li> <li>106 – LTE 6 Band</li> <li>107 – LTE 7 Band</li> <li>108 – LTE 8 Band</li> <li>109 – LTE 9 Band</li> <li>110 – LTE 10 Band</li> <li>111 – LTE 11 Band</li> <li>112 – LTE 12 Band</li> <li>113 – LTE 13 Band</li> <li>114 – LTE 14 Band</li> <li>117 – LTE 17 Band</li> <li>118 – LTE 18 Band</li> <li>119 – LTE 19 Band</li> <li>120 – LTE 20 Band</li> <li>121 – LTE 21 Band</li> <li>122 – LTE 22 Band</li> <li>123 – LTE 23 Band</li> <li>124 – LTE 24 Band</li> <li>125 – LTE 25 Band</li> <li>126 – LTE 26 Band</li> <li>127 – LTE 27 Band</li> </ul>

	<p>128 – LTE 28 Band          131 – LTE 31 Band          133 – LTE 33 Band          134 – LTE 34 Band          135 – LTE 35 Band          136 – LTE 36 Band          137 – LTE 37 Band          138 – LTE 38 Band          139 – LTE 39 Band          140 – LTE 40 Band          141 – LTE 41 Band          142 – LTE 42 Band          172 – LTE 72 Band</p>
<channel>	<p>Frequency channel, the range is different according to different band          GSM 850: 128~251          GSM 900: 1~124, 975~1023          GSM DCS 1800: 512~885          GSM PCS 1900: 512~810          WCDMA IMT 2000: 9612~9892          WCDMA PCS 1900: 9262~9542          WCDMA 800: 4132~4242, 782~862          WCDMA 850: 4132~4242, 782~862          WCDMA 900: 2712~2872          LTE 1: 18000~18599          LTE 2: 18600~19199          LTE 3: 19200~19949          LTE 4: 19950~20399          LTE 5: 20400~20649          LTE 6: 20650~20749          LTE 7: 20750~21449          LTE 8: 21450~21799          LTE 9: 21800~22149          LTE 10: 22150~22749          LTE 11: 22750~22949          LTE 12: 23010~23179          LTE 13: 23180~23279          LTE 14: 23280~23379          LTE 17: 23730~23849          LTE 18: 23850~23999          LTE 19: 24000~24149          LTE 20: 24150~24449          LTE 21: 24450~24599          LTE 22: 24600~25399          LTE 23: 25500~25699          LTE 24: 25700~26039          LTE 25: 26040~26689</p>

	<p>LTE 26: 26690~27039          LTE 27: 27040~27209          LTE 28: 27210~27659          LTE 31: 27760~27809          LTE 33: 36000~36199          LTE 34: 36200~36349          LTE 35: 36350~36949          LTE 36: 36950~37549          LTE 37: 37550~37749          LTE 38: 37750~38249          LTE 39: 38250~38649          LTE 40: 38650~39649          LTE 41: 39650~41589          LTE 42: 41590~43589          LTE 72: 133472~133521</p>
<power>	<p>For LTE:The power between 0~2000apc, the value is different with different band          For GSM: The power means afcDac, the value between 0 and 1023. suggested range is (200-700) (too bigger will cause Tx saturated, and equipment could not detect it)</p>
<bandwith>	<p>Rx band width:0~5.if it is WCDMA,this value must be set to 0.</p> <ul style="list-style-type: none"> <li>0 1.4M</li> <li>1 3M</li> <li>2 5M</li> <li>3 10M</li> <li>4 15M</li> <li>5 20M</li> </ul>
< rssiValue >	The Rx Power for GSM/WCDMA
< mainRssiValue >	The Main ant Rx Power for LTE
< secRssiValue >	The Sec ant Rx Power for LTE

## 3 CTBURST Examples

```
AT+CFUN=0 //Minimum functionality. You can also set
           AT+CFUN=4
OK
AT+CTBURST=0 //Close TX/RX CTBURST
+CTBURST: TX/RX OFF
OK
AT+CTBURST=1,101,18300,2000 //Start RF TX Power of LTE BAND1 the arfcn is
                             18300 the power is 2000apc
+CTBURST: TX ON
OK
AT+CTBURST=2,101,18300,2000,5 //Start RF RX Power of LTE BAND1 the arfcn is
                                18300,mainrssi is -60 secrssi is 0
+CTBURST: RX: -60, 0
OK
AT+CTBURST=1,1,124,200 //Start RF TX Power of GSM900 the arfcn is 124
                        the power is 200afc
+CTBURST: TX ON
OK
AT+CTBURST=2,1,124,200,0 //Start RF RX Power of GSM900 the arfcn is 124
+CTBURST: RX: -60
OK
AT+CTBURST=1,10,9650,2000 //Start RF TX Power of WCDMA IMT 2000 the
                            arfcn is 9650 the power is 2000apc
+CTBURST: TX ON
OK
AT+CTBURST=2,10,9650,2000,0 //Start RF RX Power of WCDMA IMT 2000the
                              arfcn is 9650
+CTBURST: RX: -60
OK
```